

# Tray Dryer / Drying Oven

## NSW-148 B TRAY DRYER (FOR SEED, LEAVES, VEGETABLES & FRUIT DRYING)

**CONSTRUCTION:**

- This is triple walled, inside and outside mild steel, outer painted in dark chocolate color.
- Trays are made of Aluminium having size 800 x 400 x 30mm.
- Insulation between the two walls is filled with mineral wool.
- It is fitted with Microprocessed Electronic Digital temperature indicator cum controller and circulation fan also to get uniform temperature form plus/minus 3°C. above ambient to 250°C.
- These dryer are available in capacity of 12, 24, 48, 96 & 192 trays
- To work on 220/440V AC.



NSW-148 B

**SIZE OF DRYER INSIDE CHAMBER:**

MODEL	SIZE (MM)			NO. OF TRAYS
	W	D	H	
TDMS-1	425	835	910	12
TDMS-2	910	835	910	24
TDMS-3	1420	3475	1420	48
TDMS-4	1420	1665	1420	96
TDMS-5	1420	3425	1420	192

**OPTIONAL:**

- Microprocessed PID Controller having 4 ramp & 4 soak profile having set mode, alarm parameter, configuration parameter, profile parameter, set point profile, Pv error indicator, parameter for locking etc. to cost extra.
- Alarm: It is possible to provide electronic alarm if, temperature deviates more than ± 5°C to cost extra
- Electronic Hooter (three tone) to cost extra.
- Automatic timer electronic 9999 mts to cost extra.
- **Extra price for Inner chamber & Outer Chamber SS-304 Qlty or SS-316 Qlty to cost extra.**



NSW-148 B